

RocketStor 6314B

Thunderbolt™ 2 Hardware RAID
4-Bay Storage Enclosure with
with Thunderbolt™ 3 to
Thunderbolt™ 3 adapter

Quick Installation Guide

V1.00

1

Contents

HighPoint RocketStor 6314B	3
Key Features.....	3
Kit Contents	4
RocketStor 6314B Hardware.....	4
Panel Layout-Front View	4
Panel Layout-Rear View	5
Thunderbolt 3 to Thunderbolt 2 Adapter	5
Setup Enclosure	6
Setup the RocketStor 6314B under Mac	9
1. Verify the RocketStor 6314B's RAID Controller Driver	9
2. Install the Mac Driver for the RocketStor 6314B.....	9
3. Install the HighPoint RAID Management Utility(WebGUI):.....	10
4. Using the WebGUI	10
Setup the RocketStor 6314B under Windows.....	11
1. Driver Installation: Windows	11
2. Install and Start the RAID Management Utility.	12
3. Running the WebGUI	12
Customer Support.....	13

2

HighPoint RocketStor 6314B

HighPoint's RocketStor 6314B Thunderbolt™ Storage Solution delivers high-performance, hardware RAID storage from a single cable connection!

The fully integrated hardware RAID controller and removable disk modules were designed for today's fastest 6Gb/s storage devices - perfect for professional, I/O intensive applications such as digital content creation and media post production. The RocketStor 6314B's robust, stylish aluminum construction ensures your storage stays cool while running at optimum efficiency.

Key Features

- Stylish, compact and Whisper-Quiet Enclosure
- Thunderbolt™ 2 interface with 20Gbps of throughput in both channels with Thunderbolt 3 connection
- 3.5" and 2.5" SAS/SATA Removable Disk Tray Modules
- RAID level 0, 1, 10, 5, 6 & JBOD
- Comprehensive Storage Management Suite

3

Kit Contents

- Enclosure x 1
- Disk Tray x 4 (Installed)
- Hard Disk Drive mounting screw x 2 set (3.5" and 2.5")
- Thunderbolt™ cable x 1
- Power Cord x 1
- Thunderbolt 3 to Thunderbolt 2 Adapter

RocketStor 6314B Hardware

Panel Layout-Front View



Device Present & Active LED: Solid/Flash Blue - HDD Access Indicator
Device Status LED: Solid/Flash Red - Device Failure / Rebuilding Indicator
Enclosure Power LED: Solid Blue - Power on Indicator

4

Panel Layout-Rear View



Thunderbolt™ connectors: Connecting Thunderbolt cables

AC Power IN receptacle: Connecting AC power cord.

Power switch: Enclosure power switch.

Kensington Lock Slot: Optional slot for Kensington Lock

Note: Enclosure power supply AC INPUT 100-240V ~ 5A 50/60Hz

Thunderbolt 3 to Thunderbolt 2 Adapter

It allows HighPoint Thunderbolt™ 2 RAID enclosures to be used with Thunderbolt™ 3 (USB-C) ports



5

For 2.5" disk: Use the 2.5" screws (silver color) to mount the disk to the bottom of the disk tray.



3. Connect the RocketStor 6314B to the host system with the Thunderbolt™ cable, and then connect the RocketStor 6314B with a power source.



7

Setup Enclosure

1. Place the RocketStor 6314B on a level surface and remove each disk tray.



2. Carefully insert the 3.5" or 2.5" disk into each disk tray and secure them with the provided mounting screws.

For 3.5" disk: Use the 3.5" screws (black color) to mount the disk to each side of the disk tray.



6

4. With the power cord connected to the power source, turn on the RocketStor 6314B using the power switch on the rear panel (switch to the "I" position to power on the RocketStor 6314B).



5. RocketStor 6314B is designed to be powered on and powered off simultaneously with the HOST system, when the RocketStor 6314B is connected to the HOST system with the Thunderbolt™ cable. Therefore, power on the host system first – the RocketStor6314B will automatically power on.




8

Setup the RocketStor 6314B under Mac

1. Verify the RocketStor 6314B's RAID Controller Driver

After connecting the RocketStor 6314B to the Mac system using the Thunderbolt™ cable and powering on the device, OS X should detect the RocketStor 6314B's RAID controller, and display it under PCI Cards. Check the “Driver Installed” status for the “RocketRAID 4520 SAS Controller”.



- “Yes” means the driver is loaded and working properly.
- “No” means the controller is detected but the driver has not been installed”.

2. Install the Mac Driver for the RocketStor 6314B

To download the Mac driver, please visit the RocketStor 6314B's downloads page:

http://highpoint-tech.com/USA_new/series-rs6314b-download.htm

After downloading the software, double click the .dmg package to extract and double click the .pkg file to start the installation. Please follow the installation wizard to complete the driver installation.

9

3. Install the HighPoint RAID Management Utility(WebGUI):


The Mac WebGUI is available from the RocketStor 6314B downloads page:

http://highpoint-tech.com/USA_new/series-rs6314b-download.htm

After downloading the software, double click the .dmg file to extract software package and double click the .pkg file to install the Mac WebGUI. Follow the installation wizard to complete the WebGUI installation.

4. Using the WebGUI

Start the WebGUI by double-clicking the icon found on the desktop:



Please download the user's manual for more information:


http://www.highpoint-tech.com/PDF/RS/RS6314A/RS6314X_User_Manual_v1.03_19_02_15.pdf

10

Setup the RocketStor 6314B under Windows

1. Driver Installation: Windows

- 1) Boot up the Windows operating system.
- 2) Make sure the host system's Thunderbolt™ driver has been installed.
- 3) Open the Windows Device Manager. The RocketStor 6314B will be recognized as a RAID controller under “Other devices”.



- 4) Download the Windows driver package from the RocketStor 6314B's downloads page: http://www.highpoint-tech.com/USA_new/series-rs6314b-resource.htm
- 5) Extract the package and click the setup.exe program to install the driver. The installation program will install the RocketStor 6314B's driver, automatically.
- 6) After rebooting the system, the RocketRAID 4520 will be recognized by Device Manager, and listed under “Storage Controllers”.

2. Install and Start the RAID Management Utility.

- 1) Download the RAID Management Utility (WebGUI) from the RocketStor 6314B's downloads page: http://highpoint-tech.com/USA_new/series-rs6314b-download.htm
- 2) Extract the package and double Click the Installation program to start installing WebGUI for Windows.

11

3. Running the WebGUI

- 1) After installation is complete, a WebGUI icon will be displayed on the desktop.



Double-click this icon to open the WebGUI. The system's default web browser will open a login page. To login, use the default user name: RAID and password: hpt.



Please download and check the RocketStor 6314B user's manual for more

information about the WebGUI: http://www.highpoint-tech.com/PDF/RS/RS6314A/RS6314X_User_Manual_v1.03_19_02_15.pdf

Customer Support

If you encounter any problems while utilizing the HighPoint RocketStor 6314B, or have any questions about this or any other HighPoint Technologies, Inc. product, feel free to contact our Customer Support Department.

FAQ: <http://www.highpoint-tech.com/websupport/kbn.php>
Web Support: <http://www.highpoint-tech.com/websupport/>

HighPoint Technologies, Inc. websites:
<http://www.highpoint-tech.com>

© Copyright 2019 HighPoint Technologies, Inc. All right reserved.

12