

## Marble Madness

## Commodore-Amiga

### Getting Started

Start your Amiga with Kickstart and insert the *Marble Madness* disk at the "Insert Workbench" screen. If your Amiga is already on, reboot with **Control-Amiga-Amiga** and insert the *Marble Madness* disk. When the Workbench appears, double-click the *Marble Madness* disk icon to open the disk window, then double-click the *Marble Madness* program icon to start the program.

After a few moments the title screen appears, followed by the *Marble Madness* options menu. Only the mouse can be used to make choices in the options menu. The default *game play* options are for one player using a joystick plugged into the rear port. Click **GO!** at the bottom of the screen to play the game with the default settings.

### Changing Options

You can change any of the other options by clicking the appropriate option. Click **Number of Players** to toggle between one or two players. The default control device for the Blue Player (Player 2) is the mouse plugged into the front port. You can change either player's control device and port by clicking the **Input Device**, and the **Red Player** or **Blue Player** options.

In addition to mice and joysticks, *Marble Madness* also supports two types of trackballs. Trackball 1 is a device that behaves just like a joystick internally, while Trackball 2 is a device that behaves like a mouse internally. Refer to the documentation provided with your trackball to determine which setting you should use.

The final player-adjustable option is the **Difficulty** level. There are eight levels of difficulty numbered from 0 to 7. 0 is the easiest level and should be used by first-time players. Each time you click **Difficulty**, the option advances to the next highest level of difficulty. Clicking at level 7 returns the option to 0.

When you are finished playing *Marble Madness*, eject the program disk and reboot your Amiga.

## Controlling Your Marble

The Amiga version of *Marble Madness* contains an option that lets you turbocharge your marble. Simply press the joystick, trackball, or left mouse button as you steer to give your marble an extra burst of speed.

## Acknowledgements

Larry Reed would like to thank Steve Hayes and Bill Lee for tireless commitment to debugging, optimization, and sounds; Jon Medek for testing beyond the call of duty; Stewart Bonn for maintaining a great attitude in spite of Larry's attempts to make him miserable; Greg Riker, Dave Maynard, Rich Hilleman, Norm Noble, and the rest of Electronic Arts' technical staff for bringing the development process out of the dark ages; Jay Miner and the folks at Amiga for building a great machine; and to everyone else at Electronic Arts' for their help in making *Marble Madness* a reality.

## LIMITED WARRANTY

Electronic Arts warrants for a period of ninety (90) days from the date of delivery that, under normal use, the magnetic media upon which this program is recorded will not be defective; that, under normal use and without unauthorized modification, the program substantially conforms to the accompanying specifications and any Electronic Arts authorized advertising material; and that the user documentation is substantially complete and contains the information Electronic Arts deems necessary to use the program. If, during the ninety (90) day period a demonstrable defect in the program or documentation should appear, you may return the software to Electronic Arts (or Electronic Arts' authorized representative) for repair or replacement, at Electronic Arts' option. If Electronic Arts (or "its authorized representative") cannot repair the defect or replace the software with functionally equivalent software within thirty (30) days of Electronic Arts' (or "its authorized representative's") receipt of the defective software and unless Electronic Arts and customer have agreed otherwise, then customer shall be entitled to a full refund of the license fee. Following the initial ninety day warranty period, defective media will be replaced for a replacement fee of \$7.50. Defective media should be returned to: Electronic Arts, 390 Swift Avenue, South San Francisco, CA 94080. Enclose it in protective packaging, accompanied by (1) proof of purchase, (2) a brief statement describing the defect, (3) a \$7.50 check (if beyond the initial ninety day warranty period), and (4) your return address.

## WHAT IS NOT COVERED BY THIS WARRANTY

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO NINETY DAYS FROM THE DATE OF PURCHASE. ELECTRONIC ARTS SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Address all correspondence to Electronic Arts, 1820 Gateway Drive, San Mateo, CA 94404. Or call us at (415) 572-ARTS.

Commodore-Amiga AmigaDOS and Workbench routines copyright © 1985. Commodore-Amiga, Inc. All rights reserved.

Unless identified otherwise, all programs and documentation are © 1986 Electronic Arts.

117503