Keyboard Controls

NOSE DOWN

([SHIFT]-[9] FOR FULL THROTTLE)

INCREASE THROTTLE

LEFT ROLL (AILERON)

RIGHT ROLL (AILERON)

CENTER AILERONS AND ELEVATOR

([SHIFT]-[5] TO LEVEL BANK, AND [SHIFT]-[5] AGAIN TO LEVEL PITCH.)

DECREASE THROTTLE

([SHIFT]-[3] TO CUT THROTTLE

AIR & GROUND BRAKES

NOSE UP

FIRE MACHINE GUNS

AIRCRAFT CONTROLS

MULTIPLAYER TEXT CURSOR TOGGLE

COARSE ZOOM

EXIT TO MENUS

1ST 3D

2ND 3D

RADAR

MAP

MULTI PLAYER

MOUSE/ YOKE SELECT

OUT   IN

[SHIFT]-[F9] AND [SHIFT]-[F10] FOR RADAR ZOOM CONTROL

MENU CONTROL

FINE ZOOM

SET 1X ZOOM

SELECT PRESET WINDOW CONFIGURATION
PRESS SHIFTED NUMBER TO SAVE WINDOW PRESET

OUT   IN

MEDALS DISPLAY

SOUND ON/OFF

ATTITUDE INDICATOR ON/OFF

RANGE CIRCLE ON/OFF

FULL SCREEN TOGGLE

FIRE CURRENT WEAPON

FIRE MACHINE GUNS

SELECT NEXT WEAPON

GEAR UP/DOWN

PAUSE

PLACE TOWER AT JET LOCATION

VIEW LOCKED MIG

MISSILE EYE'S VIEW

TRACK

LOCK VIEW BEHIND PLANE

CONTROL TOWER

DOWN

SPOT

COCKPIT

VIEW MODE CONTROLS

VIEW DIRECTION CONTROLS

TOGGLE WINDOW TITLES

LAUNCH FROM CATAPULT [SHIFT]-[L]

FASTER SCENERY TOGGLE

MISCELLANEOUS CONTROLS

[SHIFT]-[R] TO REPAIR, REFUEL & REARM IF AT BASE
[SHIFT]-[E] TO EJECT
[SHIFT]-[N] TO ABORT EJECTION & FLY IMMEDIATELY